

CAR / TRUCK &gt; CAR / TRUCK - INFLATION AND CONTROL

**L-RING**Code: **MGO01MXXX0003**

The "L" type rings (L Ring) are used as an air seal device when the tire bead comes into contact with the rim stop point. This may be particularly necessary when the surface of the heel stop is not fully compatible with the tire bead.

**TOSI SNC**