

MOTORBIKE > BIKE - CTEK BATTERY CHARGERS > CTEK ACCESSORIES BIKE

**CS FREE USB C/ACCENDIG.40-464
CHARGING CABLE**Code: **MAA02XXXX0091**

The USB-C CHARGE CABLE 12V PLUG socket makes it easy and safe to charge the internal battery of your CS FREE on the go or when your vehicle is parked. Simply connect it to the vehicle's 12 V cigarette lighter or auxiliary socket * and connect the USB-C plug to the CS FREE's charge input port.

The USB-C CHARGE CABLE 12V PLUG has a robust, durable and flexible cable designed and rigorously tested in Sweden.

(*) Please note that the socket must also be powered when the ignition is in the 'OFF' position.